



### **PE BALL VALVE**

### **INSTALLATION GUIDELINES AND WARNINGS**

# **INSTALLATION**

- Observe local installation standards, manuals and drawings.
- Observe standard butt fusion or electofusion installation methods
- Protect products by storing indoors and in plastic bags protecting cap before installation.
  - The item should be installed by a certified fusion technician
  - The installation of the product is in accordance with the instructions provided

### **USE**

- Handle: 2" square operation nut for all sizes
- Connection: after attaching key extension, put the handle at the top of the extension
- Open/Close method:
  - -In order to close, turn clockwise 90° from open location
  - -In order to open, turn counterclockwise 90° from close location
- Products are not exposed to temperatures and/or pressures that exceed the limitations printed on the product or in the installation manual.



# **WARNINGS**

- 1. Handle with care in order to avoid damaging the valve
- 2. Follow proper installation methods and use only in appropriate applications
- 3. For use in approved water applications
- 4. Always keep the valve clean and free from internal and external debris
- 5. Do not apply excessive force when opening and closing the valve
- 6. Keep the valve away from flames and excessive heat
- 7. This valve cannot be disassembled or repaired
- 8. Appropriate support of valve is critical in all buried and above ground installations